SIEMENS

C 25

User guide

Precautions

All radio transmitters carry risks of interference with electronics in close proximity:

Mobile phones must be switched off in an aircraft.

Do not use close to refuelling areas, fuel depots, chemical plants, blasting operations or hospitals.

Minor interference may affect TV's, radios, phones, etc.

Personal medical products (pacemaker, hearing aids, etc.) can be affected.

Do not hold phone in your hand whilst driving.

Please note:

Do not dismantle phone or battery (no user serviceable parts).

Use only specified battery, others can damage the phone or even explode. Also avoid contacts shorting.

Exhausted batteries should be recycled. Dealers and local facilities provide special containers.

There may be risks of damage when using non ORIGINAL accessories.

Introduction

Welcome to GSM, the international mobile phone service available in more than 100 countries. Your phone will work on both GSM 900 and 1800 networks. You should check with your Operator regarding current and planned coverage (areas of service).

In addition to enabling basic phone calls, your phone, and network provide many valuable features and services to enhance business and leisure use.

If you experience difficulties, Siemens provide a dedicated help-line in most countries around the world (see page 28).

Your User Guide

Your 'Quick Start' will help you quickly use basic functions.You should also read this User Guide for complete, safe, and effective operation of the phone and network features.

The following symbols are used:

	Use the keypad to write numbers or letters.
	Use the soft key, function displayed above.
	Press indicated end of soft key.
	Network dependent feature.
OK	Bold text indicates a soft key, or displayed function.

Contents

Getting Started 2

1. Insert SIM Card 2
2. Fit and Charge Battery 2
3. Switch on 3
4. Enter PIN 3

Making Calls 4

Dialling with Keypad 4
Redialling your Last Call 4
Redialling Previous Calls 4
Auto Redialling 4
Calling Back 4
Missed Calls 5
International Dialling 5
Answering Calls 5
Unwanted Calls 5

PhoneBook 6

Writing in PhoneBook 6
Calling from PhoneBook 6
Control Codes (DTMF) 7

Applications 8

During a Call 8

Volume Control 8
Recording a Number 8
Call-Time, Charge 8
PhoneBook/Last Calls 8
Call Waiting 9
Hold Call 9
Multi Party Calls 9

Menu Use 10

VIP Dial 11

Setting from PhoneBook 11
Setting a New Number 11
Using VIP Dialling 11

Text Message 12

Reading a Text Message 12
Deleting Messages 12
Message List 13
Sending New Message 13
Replying to Message 15
Sending on Message 15

CB Cell Broadcast 15

Voice Mail 16

Hearing Voice Mail 16
Setting Voice Mail 16
Divert to Mailbox 16

Ringer/Tones 17

Ringer Volume: 17
Ringer Melody 17
VIP Dial Melody 17
Service Tones 17
CB Tone 17
Key Sound 17
All Tones (on/off) 17
Record Melody 17

Extras 18

Time/Charge 18
Divert (advanced) 19
Message Setup 19
Cell Broadcast Control 20
Language 20
GSM Service 20
Security 21
Car Use (also Headset) 22
Applications 22

Display / Symbols 22

Trouble Shooting 23

Specifications 25

Licensing 25
Technical Specification 25
Care of Your SIM Card 25

Accessories 26

International Code + Services . 28

Index 29

1. Insert SIM Card

Your Service Provider will supply a SIM card, containing your phone number and billing details. It may be used in other GSM phones. You may need to carefully snap this out from a credit card sized SIM.

- Remove rear cover and battery if fitted.



- Locate SIM card, gold contacts down, angled corner top left.
- Slide SIM fully into position.



2. Fit and Charge Battery

- Locate battery as shown (contacts on top end).



- Refit cover, ensure top end is located flush before swinging closed (until it clicks).

If removing battery ensure phone is switched off first.

To charge battery:

Your new battery will not be fully charged:

- Insert charger plug into socket in base (arrow facing up).



squeeze to release

- Plug charging unit into mains power socket (ensure voltage stated on charger is not exceeded).
- Allow at least 8 hours for your first few charges, subsequently allow 5 - 6 hours for maximum charge.

Your display shows charge level. You may use your phone whilst charging.

Usage Time

A full charge can provide up to 100 hours standby, or 5 hours talktime - subject to network and environmental conditions.

A beep sounds when nearly empty.

3. Switch on

Hold down to switch on or off.

If „insert SIM Card“ is displayed, please check that it is correctly orientated and seated (step 1). Note, an older SIM type may not be compatible, please check with your Service Provider (3 volt SIM required). See also "Trouble Shooting", p. 23.

4. Enter PIN

Your SIM card may be provided with a PIN code to prevent misuse.

Enter your PIN code.
(Correct errors with ←C)



Press

Your phone will register with Network, this may take some seconds.

You are ready to make and receive calls when Operator's name appears.

May also appear if your SIM is enabled for special Applications (page 10).

Emergency Call

Press soft key to access emergency service (without a SIM).
You can always dial 112 (999 in UK).
Please do not abuse this service.

PIN

SIM card will be blocked after third incorrect PIN entry. In this case, or if you forget your PIN, see p. 23.

To switch off PIN control or change your PIN number, see p. 21.

Network connection:

Incoming signal strength.

If it is very weak, there may be risks of call quality or continuity.

You can normally improve reception by moving to window, elevated or open space.

Your phone will automatically select another network if you are abroad, or outside your 'home' network.

Dialling with Keypad



Operator name must show in display.

Dial required number.

Use always full **area code**, even if calling locally.

←C Use to correct any errors. A short press clears last digit, a long press the total number.

Call displayed number.

Press to end your call.

Usually your call ends if the other party ends it, but you should not rely on this.

Easier Ways to Call

For easier, quicker, and error free use, you can:

- Redial previous calls
- Automatically redial failed calls
- Call back received calls
- Call back unanswered calls
- Use your PhoneBook.
- Use your VIP Dial List
- Call numbers in messages
- Call 2 or more numbers at once

You may use your **Menu** (see p. 10) or proceed as follows:

Last Calls

Your phone remembers the last numbers called (and received).

From your standby display:

Redialling your Last Call

Press twice.

Redialling Previous Calls

Press.

Scroll to see previous calls.

Press to call displayed number.

Auto Redialling

If a call is unsuccessful you are offered:

Redial Press to repeatedly dial number in progressive intervals for 15 minutes.

Any other use of phone will clear this.

Calling Back

The last 'identified' calls you have received are recorded.

Shows your last calls list.

Scroll left for quickest access to last received call list.

Press to call displayed number.

Caller Identity may be not available on all connecting networks.

Missed Calls

Will appear in your display.



Press

Press to call displayed number, or scroll to display further missed calls.

Your Missed Call list can also be recalled via the **Menu** (see p. 17).

International Dialling

Hold down until ' + 'appears, providing international access from all countries.

Enter country code (see p. 28), then dial national number (omitting leading digit for most countries).

For later use abroad, save 'home' country numbers with this prefix (see p. 6).

Answering Calls

Answr Press

or

Press.

Ending Calls

Press.

Usually your call ends if the other party ends it, but you should not rely on this.

Unwanted Calls

Busy Select.

Divert will be offered instead, (if set) eg. Voice Mail (see p. 16).

or

Press to reject call.

Alternative Line

It may be possible to subscribe to a second 'alternative' phone number/ line. You may switch lines by:

Press, your softkey offers:

Line **1** (**2**) Press to switch line

Writing in PhoneBook

Dial complete number including area code, as usual.

For easier use abroad, enter international code + (p. 5).

Save Press.

Write name, number keys now write letters (see below).

OK Press.

Dial number if required

or

Press to return to standby, ready for next entry.

Writing Names

Press number / letter keys repeatedly. The cursor advances after a short delay.

Press once for 'A', twice for 'B' etc.. Available characters are displayed on the bottom line.

←C Press to erase letter preceding cursor, hold down to erase name.

Press to manually switch 'letter' case (normally the first letter is UPPER CASE, switching automatically to lower case.

Press to create space

Other characters

0+ * #

These keys write punctuation, common symbols and cyrillic.

Available characters are displayed when you press a key. See also p. 14

Hints

- Use VIP Dial (p. 11) for frequently used entries.
- You may enter a range of numbers for same person eg.
  Carol O (Office)
  Carol M (Mobile)
  Carol H (Home)
- Each entry can include up to 40 number/code combinations.

Calling from PhoneBook

Press to open PhoneBook (Own number see page 7).

/→ Enter first letter of required name, and/or scroll to display required name.



Call displayed name.

Info

- In some cases your 📖 key may not be offered.
  Menu Press scroll and select 📖 PhoneBook (p. 10).
- If you have many entries starting with same letter, enter next letter and scroll backwards.

PhoneBook Options

Further options are available, when displaying an entry.

📖 Press and display required entry.

Options Press.

Scroll and select from the following:

View Entry
Shows corresponding phone number.

Edit Entry
Number is shown with flashing cursor.

←C / ⌨ Change number.

OK Press to advance to name.

Add to VIP DialList
(see p. 11)

Delete Entry
Confirm deletion with **Yes**.

Send as DTMF Code
Use to send a saved Control Code, during a call, see right.

Capacity
Entries are stored on your SIM, this shows total and free capacity.

Delete Book
You can delete all entries in your PhoneBook. Security protected by PHONECODE (see p. 21).

Control Codes (DTMF)

You can save code numbers for controlling remote services (eg. Answering Machine). To save together with the phone number, enter this first, then:

0+ Hold down until ' + ' appears. (This creates a 3 second pause). Repeat this, if a longer pause is required, then save as usual.

You can also save just the Control Code, but must use PhoneBook-Options (via Menu) to send it during a call, see left.

Info

Own Number
The first PhoneBook entry is for your own number. If your mobile number is not programmed, it will be helpful to enter it here.

Set Press

⌨/**OK** Enter number

If your SIM provides an alternate line (line 2) you can view or set the second number.

Services PhoneBook
Your Operator or Service Provider may supply your SIM with PhoneBook entries for useful services.
If so, you will see **Service P-Book** as 3rd entry.

Applications

Your SIM may enable special applications (SIM Application Tool-Kit). These can include Banking, Booking, Information Services etc.. Please check with your Operator.

When active your standby display will show:



Press to use Application.

If more than one Application is offered:

Scroll and select as required.

Your 'Application' may offer additional 'help' information, if so

Press to read this.

Please contact your Operator for details, your phone is enabled to handle future services through this facility.

During a Call

Some operations are only available during a call.

Volume Control



Press

Use either end of left softkey.

Recording a Number

If a caller dictates a number, you can record it.

Enter phone number. The number can be dialled or saved after call.

To prevent others seeing a secure code (eg Bank PIN):

Hold down (during call).

Call-Time, Charge

This will be shown intermittently if set (p. 18).

PhoneBook/Last Calls

You may find it useful to refer to a saved number.

Menu Press.

Scroll and select:

(PhoneBook, see p. 6)

or

(Last Call List, see p. 4).

Your normal Menu functions are also available.

Call Waiting

During a call you can be advised that there is another waiting.

You may need to register for this service, and need to set your phone (p. 20).

You will hear a special tone during call. Your caller will hear ringing tone.



You have 3 options:

❶ End current call, answer new

Press to end current call, waiting call will ring and can be answered as usual.

❷ Swap

Swap or Press.

This accepts waiting call and places current call on hold. You may swap back and forth as required.

❸ Reject waiting call

Busy Caller will hear busy tone.

or

Divert This is offered instead if set (see p. 21).

Hold Call

Explain your intention (i.e. to confer with others).

Press, the call is held.

Back Press to return.

Multi Party Calls

You can call new number, swap back or join them together. During a call, explain your intention then:

Dial new number or use PhoneBook (via **Menu**).

Press, to hold the first call, and speak to the new party.



You have 3 options:

❶ Swap

Swap or Press.

This returns to the held call and places current call on hold. You may swap back and forth.

❷ End / Return

Press to end current call.

You should press **Yes** to return to held call.

❸ Join

Join Select to provide a 3 way conference. You may repeat this, adding a maximum of 5 calls.

Menu Use

Menu Principles

Your menu enables you to set up and use phone and Network features.

Press

Scroll horizontally to display required top menu.

Select Press.

Selecting an entry from Menu leads to a submenu, and sometimes further submenus.

Hold down to exit (return to normal standby state).

A short press steps back to the previous menu.

Note: Holding down when in standby will switch off.

Last Menu Use

Your phone remembers your last 7 Menu tasks. You can simply repeat, modify or clear them. From standby:

Press, your softkey offers:

Re-Use Press, scroll and select from list.

The list is cleared when you switch off.

Short Cut

Menu functions are numbered. You may also select directly by entering successive location numbers eg.

Menu 2,3 will select your Message list.

Alternative Line (see p. 5)

If you subscribe to a second phone line, you may set each menu entry specific to this line (eg. a different ring, divert, security). You must however select the required line before entering the menu.

Network Feature

Some Network features may not be currently offered by your Operator, or may require registration.

Indicates network dependent feature.

When set, you can call by just dialling one digit:

Setting from PhoneBook

Press (see p. 6).

Display required entry.

Options Press.

Scroll and select **Add to VIP DialList**.

Record VIP Dial No. for future use. If list is full, choose entry to swap.

Setting a New Number

Menu Press (menu use p. 10).

Select.

Scroll and find **<empty>** (see below if all are occupied).

Set Press

Enter number and name (p. 6).

Entry 1 is reserved for Mailbox.

If all positions are occupied:

Display unwanted entry (**Mailbox** not removable).

Options Press.

Scroll and select either:

Move Entry

Scroll left, and choose **<Move to P-Book>**

or

Remove Entry

Then proceed as from **<empty>** above.

Using VIP Dialling

Press VIP Dial (1 - 9) number.
The name (first 6 letters) will show above your right softkey.

Press to call.

or

Press.

Other Options

When a VIP Dial Entry is displayed:

Options Press.

Scroll and select from the following:

View Entry

Displays corresponding number.

Edit Entry

Change number then name.

Move Entry

You can choose **<Move to P-Book>** or to assign a new VIP Dial number:

Scroll to unwanted entry, and **Replace** it.

Remove Entry

Send as DTMF Code (see p. 8)

Info

You can set a distinctive Ringer Melody to recognise calls matching your VIP Dial list (see p. 17).

PhoneBook entries which are also in your VIP Dial list are preceded by VIP number.

Text Message

Your phone can receive and send text messages (SMS). Your Operator will advise you concerning service availability and conditions.

Reading a Text Message

A **new** message is indicated by an additional symbol:



Press

The display indicates the date and time received, also the originator's number.

Scroll through message.

You can call any highlighted ▸Number:◂.

Deleting Messages

At end of message you are asked to delete it:

Yes Press.

You should normally delete a message since capacity (of SIM card) is limited, and when full, you cannot receive more messages.

Will flash, if your SIM is full (see p. 13).

Options (whilst reading new)

Options Press.

Scroll and select from the following:

Call number shown
This may be originator, or another number in message.

Save Number shown
Saves number in your PhoneBook.

Reply
There are a number of options, see p. 14.

Delete
Deletes message (see left).

Edit
Follow procedure for sending message (p. 13).
←C use as required.
Use also for sending on to a new destination.

Capacity
Shows number of saved messages and free capacity.

Return to List
Returns to message list (p. 13).

Message List

Menu Press (menu use p. 10),

Scroll and select
✉ **Text Message**

Scroll and select
✉ **Out** (Outgoing List)

or

✉ **In** (Incoming List)

Scroll through list.

1/3 List position / length.

✉? Message without address.

After a short delay, the message scrolls automatically.

Options (in ✉ list)

Options Press

Scroll and select from the following:

Read Entry

Press to scroll manually, this also enables all 'reading' options (p. 14).

Delete Entry

Deletes message (p. 14).

Edit Entry

Follow procedure for sending message (p. 13).
←C use as required. Use also for sending on to a new destination.

Capacity

Shows number of saved messages and free capacity.

Sending New Message

You will be prompted to enter your Service Centre number* when sending your **first** message (available from your Operator).

Menu Press (menu use p. 10).

Scroll and select
✉ **Text Message**
then **<Create new Msg.>**

Write Message using alphanumeric keypad (p. 14).

OK Press when complete.

Yes Confirm 'End of Entry' (**No** provides other options see p. 14).

Enter Service Centre number if requested.

Enter number or select from PhoneBook.

OK Confirm 'Destination'.

OK Send message (confirming 'Normal Text', to change see p. 20).

or

Press to send.

You are advised when your message has been sent, then you can save it. It will appear in your ✉ **Out** message list.

* If you need to change Service Centre number, see p. 20.

Text Message

Writing Letters

Press number / letter keys repeatedly. The cursor advances after a short delay.

- 2 ABC — Press once for 'A', twice for 'B' etc.
- 1 — Press to create space.
- ←C — Press to erase letter preceding cursor.
- * — Press to switch between UPPER- and lower case letters.
- 123 — For numbers first step through letters.
- ← → — Press long to move cursor word by word, short moves letter by letter.

Other characters

0+	+	0	-	.	,	:	;	'
	"	?	¿	!	¡	_		
*	*	/	(	)	<	=	>	%
	&	§	£	$	€	¥	¤	@
#	#	Γ	Δ	Ξ	Λ	Ε	Π	Σ
	Φ	Ψ	Ω					

Info

- If your message is not sent, you are offered **Retry?**. If this fails, check that your Service Centre is correctly set and that the destination phone is compatible (p. 19).
- Note that 'Message sent' means it has been received by your Service Centre, if it cannot be immediately delivered, it will be continuously retransmitted.

Re-Usable Messages

You may find it useful to keep list of 'standard' messages, which can be routinely edited and resent. You can create messages yourself, or edit messages sent by others.

Options (whilst writing or editing)

OK — Press to display 'End of Entry?'.

No — Press.

Options — Select.

Scroll and select from the following:

Edit Message
Returns to editing/writing.

Insert from P-Book
Opens PhoneBook for inserting a number.

Insert new Line
Start new paragraph.

Discard Message
Returns to message list without saving.

Replying to Message

Display message:

Options Press.

Scroll and select **Reply**.

You have 4 options:

❶ **'Answer is YES'**

❷ **'Answer is NO'**

These footnotes plus your number are added to the response

❸ **Create new Response**

You can write a new message (p. 13)

❹ **Edit Response**

You can change content first (use ←C).

OK / Yes Confirm.

OK Send message (confirming 'Normal Text').

Sending on Message

Display message:

Options Press.

Scroll and select **Edit Entry**

Follow procedure for sending messages (p. 13), confirming **End of Entry?**, and using ←C to clear unwanted address.

Enter destination number or select from PhoneBook.

OK / OK Confirm and send.

Your Operator may offer a Cell Broadcast service, where information can be broadcast within specific cells. A range of services including traffic, weather, etc. is being developed.

Please see 'CB Topics', page 20 to switch on, and select topics.

Reading Cell Broadcast CB

A new broadcast scrolls through your display, until read manually (see below). Your network may replace a broadcast with a new one.

Reading all new Broadcasts

Press.

Read Press and scroll through broadcasts.

Read old (and new) Broadcasts

Menu Press (menu use p. 10),

Scroll and select:

Text Message then **Messages** then **Read**

Scroll to read Broadcasts (arranged by topics). Up to 25 are saved, the oldest ones will be overwritten.

You may save Broadcasts permanently in your Text Message list (see p. 13).

This network service can be provided as an inclusive service and set automatically. You may need to register for service and set it manually, please check with Operator.

Owing to different systems in use, operation could differ from that mentioned below.

Hearing Voice Mail

A waiting message may be indicated by one of following:



- will appear (plus beep).

Press to call and hear message

or

- will appear (plus beep)

Press to check text message (it may advise that you have Voice Mail waiting)

or

- Phone call/recorded announcement.

You will need to call your Message Centre to hear the message(s). You can use:

1 — Press, if set (see right).

Press to call.

Setting Voice Mail

Menu Press (menu use p. 10),

Scroll and select **Voice Mail**

Scroll and select from the following:

Call Mailbox

If not set, you will be invited to set it (if set you can edit it).

/ OK Enter 'calling' number provided by your Operator.

You may subsequently call this number:

1 — Press (from standby).

Press.

Divert to Mailbox

If not set, you need to Divert calls you do not answer (including when switched off) to your Mailbox.

Scroll and select **Divert**

Check Press to check setting (if offered). This may take some seconds.

On Switch Divert on (if it is off).

/ OK Enter 'Divert' number provided by your Operator (normally different to the number you need to call).

Divert On will appear after every call, as a reminder.

Further Divert options are available, see (p. 19).

Ringer/Tones

Menu Press (menu use p. 10),

Scroll and select **Ringer**.

Scroll and select from the following:

Ringer Volume:

You can adjust volume in 4 steps or escalating ring.

indicates escalating ring - starts quietly then increases. This can avoid unnecessary disturbance.

Ringer Melody

You can select from 20 melodies, plus an unobtrusive beep.

VIP Dial Melody

You can select a different melody which will sound when an incoming call matches an entry in your VIP Dial List - recognise important callers!

Service Tones

You can switch on/off audible signals indicating:

- Connection to the network.
- Message / CB Arrival.
- Connection after dialling.

Your 'Low Battery' warning cannot be switched off.

CB Tone

You can switch off the Tone announcing a new Cell Broadcast message.

Key Sound

Off, Click or Tone.

All Tones (on/off)

Enables totally silent operation (excludes low battery warning).

Will show to remind you

or

for quicker/easier use

Hold down (when in standby)

Change Press to select single Ringer beep if preferred.

Record Melody

You may compose your own ringer melody.

Enter tune.

PhoneBook

Your PhoneBook can be directly accessed via your 📖 (PhoneBook) key, please see p. 6. If you want to use your PhoneBook during a call, or when writing a message, select it from your menu.

Last Calls

A list of your last 10 outgoing, and incoming calls can be seen, and called by using your key, please see p. 4.

You can also access these lists via your menu, but additionally you can recheck your Missed Calls (you are alerted each time you miss a call, see p. 5).

Menu Press (menu use p. 10),

Scroll and select
Extras.

Scroll and select from the following:

Time/Charge

Last Call

You can see the duration of your last call, and if supported by your Network, the units used. You can also see the associated charge, if you have set this (see right).

Total Calls

This enables you to see the cumulative time (Units and Charge if set). It also enables you to zero these.

Auto Display

Switch on this to see elapsed time during a call, the call time will also appear briefly after each call.
Related charge is shown, if this is programmed.

Minute Beep

Switch on to hear a reminder beep every minute.

Charge Rate

If your network supports 'Advice of Charge', and you are registered for it, you will see number of Units used.

/ OK Enter valid Charge Rate per Unit (note decimal point on softkey). Your phone will calculate and display relevant charge.

/ OK Charge Rate per Minute can be entered, but note inaccuracy owing to tariff variations.

/ OK Charge Rate Currency can be named.

Charge Limit

Your phone can be set to suspend service after a predetermined number of Units have been used.

This requires a special SIM, with a second PIN (PIN 2).

When switched on, the Units limit can be entered or changed. **Info** enables you to check status.

Your Service Provider may use this feature to enable instant and possibly prepaid service.

Divert (advanced)

This network feature diverts (or forwards) calls to another phone or your Voice Message Centre.

See also Voice Mail (p. 16) for setting a simple (unanswered call) Divert. This menu offers further possibilities which may also be used for Voice Mail.

To set Divert

Scroll and select **Divert**

Scroll and select the type of Divert (see next page).

Check Press to check setting (if offered), this may take some seconds.

On Switch on (if it is off).

,OK Enter number you wish to divert to. You may also use 📖.

Divert On will appear after every call, as a reminder.

To Clear Divert

Follow setting procedure, and switch off. The destination is memorised so you can easily switch on again.

To change Divert Number

Clear Divert, then switch on.

←C / Erase the old number and enter new one.

Divert all Calls

No calls will be received by your phone.

Will show permanently if **Divert all Calls** is set.

Divert all Unanswered Calls

This general setting includes, **If not reachable, If no Reply:, If Busy:** see below.

If not reachable

Calls will be diverted when your phone is switched off, or out of coverage.

If no Reply:

Your phone will ring, but after a delay, the call will be diverted. You can change delay time (increments of 5 sec., 30 sec. max).

If Busy:

Calls are diverted when your phone is Busy.

Check all Diverts

Divert network settings may not always match your display (eg if you change SIM).

Info Press to check set destination

Clear all Diverts

You may also clear individual Diverts (see p. 19).

✉ Message Setup

✉ Service Centre Number

Enter or change the Service Centre number advised by your Operator.

Message Type

It may be possible for your Message Centre to send your SMS message(s) in other formats, please check for details. Your phone can request different formats:

Change Press, you can choose from:

Normal text, Telex, Fax, E-Mail, X.400, Define new type(enter supplied code)

Cell Broadcast Control

CB On/Off

When switched on, your standby time can be reduced.

CB Topics

When switched on, you can choose from a standard list of broadcast Topics, but note that these may not be currently available in your network.

<Add new Topic> Select

You may activate 5 Topics. Activating further new Topics will require you deactivating old ones.

Examples;

- **Normal** is the standard Broadcast supplied by your Operator.
- **Flashes** are new items of general interest.

If the list does not contain a Topic you require, select **Define new Topic?**, and enter the code provided by your Operator.

Please see p. 15 to read Broadcasts.

Language

You can select your language for the display texts. 'Automatic' will set the language normally used by your 'home' Operator.

GSM Service

Network Info

You can scroll through networks you are receiving signals from, and select service but:

Some Operators may be barred by your SIM.

Select new Network

You can change manually to next preferred Network when outside your home Network.

AutoNetwork

The automatic selection priority is controlled by your Preferred Network list. You may switch Auto Network off, and subsequently select manually.

Preferred Network

Operators on this list have priority for automatic selection. You can edit this list, deleting an entry or setting a new one as follows:

Scroll to **<empty>** and press **Set**.

You can scroll through the Operator List, choosing as required. If the required Operator is not listed, you can enter it via the Country (MCC) and Network (MNC) codes they supply.

Operator List

A list of known GSM Operators may be referenced for information.

Call Waiting

If you register for this service, you may need to set it, you can also check status. For operation see p. 9.

Incognito

Subject to your Network, and other carriers, the person you are calling may be able to see who is calling them. You may choose to conceal your identity.

Checking Status

You can check Network setting of Call Waiting and Incognito.

Security

Security Codes Information

Use of your SIM is controlled by your PIN number. Other security functions are controlled by PHONECODE, this is a 4-8 digit code, originated by you when you set the first security function (you are asked to repeat it).

SOS Emergency 112 (999 in UK) calls can always be made.



It is most important to keep PIN and PHONECODE numbers securely. The phone will be locked after three incorrect entries (your Service Provider may charge for unlocking).

Babysitter

You can restrict usage to one PhoneBook entry, switch on then:

/OK Enter PHONECODE.

/ Set entry from PhoneBook.

The standby display shows the restriction and offers the set name. Any other keypress will request PHONECODE to clear the restriction.

Lock VIP Dial

You can restrict usage to those numbers entered in your VIP Dial list. You may find it useful to change this list before locking it, (see p. 11).

PIN Setup

PIN Control

You can switch off PIN control, but note risks of unauthorised use. Note that some SIM cards will not allow this.

Change PIN Number

You can change your PIN to any 4-8 digit number (one you may remember more easily).

,OK Enter current PIN.

,OK Enter new PIN.

,OK Repeat new PIN**.**

It is most important that you record the new PIN securely, see caution note above.

Change PHONE CODE

,OK Enter current PHONECODE:

,OK Enter new PHONECODE:

,OK Repeat new PHONECODE:.

Lock to SIM

Set to prevent use of a different SIM card. If you report the loss of your phone (see p. 25) your SIM will be blocked, and no other SIM can be used.

Lock

Your SIM may enable a restricted PhoneBook, if so only listed calls may be made, and no new entries are possible. PIN2 is required to control this restriction (Fixed Dialling Number).

Car Use (also Headset)

Auto Answer

When set, your phone will answer automatically after a few rings (Note, when in a Car kit, the ignition must be on).

This is relevant only when using (onlay with optional handset):

- Car Kit Comfort (Handsfree)
- Car Kit Portable (Handsfree)
- Portable Handsfree (Headset).

Handsfree Override

To change to hand-held operation during a call (only with optional handset):

Press long (again to switch back).

Auto Power OFF

When connected with a Car Kit, your phone will switched on automatically with car ignition, and off, after 2 hours delay.

Applications

Please see p. 8 for details of this service which may be enabled by your SIM. You may normally use this service via your soft key, but if not available (eg when a message is waiting) it can be always accessed through this menu.



Soft Key Symbols	
←c	Short press clears last character, long press clears entry.
✉	Message received. Press to read it.
∞	New Voice message. Press to hear it.
→	Unanswered Call. Press to see identity.
	Applications
📖	PhoneBook
Other Symbols	
🔔	Ringer off.
✉?	Message (no address)
!	Lower level of encryption.
	Home Zone.
1 / 2	Active Line (alternative line service).
	All calls diverted (see p. 16).

Trouble Shooting

Your phone will be reliable unless it suffers from extreme shock or moisture. The following list should help you identify and remedy problems. In many SIM and network-related instances it may, however, be necessary to call your Service Provider's Customer Service Helpline.

Problem	Possible Causes	Possible corrective measures
Unable to switch on	Empty battery.	Charge it. Check charging indication in display.
	Battery contacts dirty.	Clean contacts (battery and phone). Repeat switching on and off.
	Battery replacement.	Briefly recharge.
Charging defect (no display indication)	Empty battery.	Charge for half an hour, disconnect and charge normally.
	Temperature exceeds 0 °C to + 45 °C range.	Adjust and allow time.
	Battery defective.	Replace it, after several years average use a gradual decline may be expected.
	Contact problem.	Check mains socket, and connection to phone.
SIM error	Damaged SIM card.	Make visual check. Return SIM to your Service Provider.
	SIM contact dirty.	Clean SIM contacts with a dry cloth.
	SIM card not correctly orientated.	Ensure SIM is correctly orientated.
	Incompabile SIM card.	Use only a 3 volt SIM card, please contact your Service Provider.
PIN error	3 incorrect entries.	Enter MASTER PIN (PUK), supplied with your SIM as instructed. If your MASTER PIN or PIN are lost, call your Service Provider.
PHONE CODE error	3 incorrect entries.	Contact Siemens Service.
No connection to network	Weak signal.	Move higher, to a window or open space.
	Outside GSM coverage area.	Check Operator coverage map.
	SIM not valid.	Call your Service Provider.
	New network not authorized.	Try selecting manually, or try other network (see p. 19).
Phone loses network	Weak signal.	Reconnection, or connection to another Operator is automatic. Switching off and on may accelerate this.

Problem	Possible Causes	Possible corrective measures
Calls not possible	Dialling error.	Use full national area code.
	New SIM fitted.	Check for new restrictions.
	Charge limit reached.	Call your Service Provider, or use PIN 2 to reset.
Certain calls not possible	Call restriction set.	Restrictions may be set by your Operator.
Cannot write in Phone-Book	Call restriction set.	Check PhoneBook restrictions (p. 21).
	PhoneBook is full.	Edit it (see p. 6).
Cannot find PhoneBook	SIM has been changed.	Refit original SIM.
Voice Mail not working	Divert not set.	Set divert (see p. 19).
✉ flashing	Message store full.	Delete a message to make room (p. 12).
Cannot send a message	Operator does not support this service.	Check with your Service Provider.
	Service Centre not set.	Set Service Centre (see p. 20).
	Destination does not have compatible phone.	Check.
	Message type wrong.	Check.
Cannot set a function	Not supported by your Operator, or registration required.	Call your Service Provider.
Menu entries missing	SIM Restrictions	Check with your Service Provider.
Accidents		
Severe shock	Internal damage could result.	Remove and refit battery and SIM. Do not dismantle.
Immersion in water	Internal damage could result.	Rapidly dry with cloth, do not heat. Dry contacts thoroughly. Remove and refit battery and SIM. Stand upright in moving air. Do not dismantle.

Resetting Phone

You can reset your phone to its original condition. Enter *** # 9 9 9 #**
This will not effect SIM or network settings.

Siemens Assistance/Service

Worldwide assistance is supplied by Siemens Partners - a simple phone call away.
Internet: http://w3.siemens.de/ic/products/cd/pn/ke/service/index.htm
If your phone appears faulty, please check Troubleshooting (p. 23). If the problem persists please contact Siemens Service. In the unlikely event of a defect appropriate service steps can be taken locally.

Licensing

Your phone is authorized for use in GSM networks. The phone set complies with following EU directives:

- 89/336/EWG 'Electromagnetic compatibility'
- 91/263/EWG CTR 19 and CTR 20, 91/263/EWG CTR 31 and CTR 32 'Telecommunication terminal equipment directive'
- 73/23/EWG as amended by 93/68/EWG 'Low voltage directive'

CE

Technical Specification

- GSM Class 4 (2 Watt) Frequency Range 880 - 960 MHz
- GSM Class 1 (1 Watt) Frequency Range 1710-1880 MHz

Weight	: 130 g
Size	: 116 x 46 x 28 mm (118 cc)
Standby Time	: up to 100 h
Talk Time	: up to 5 h

Innovatron Patent

- To clean, use a damp, or antistatic cloth, dry cloth could create electrostatic charges.
- Do not use chemical or abrasive cleaners, these could damage casing.
- As with most electronics products avoid extreme shock, temperature and moisture. Avoid leaving it behind glass, in direct sunlight (temperatures can exceed 60°C).

Care of Your SIM Card

- The SIM card must be treated with the same care as a bank card. Do not bend, scratch or moisten the card and take care that it is not exposed to static electricity.

Important

You are adviced to write down the following details (to help recovery of your phone).

Phone No:

.....

No of SIM card:

.....

Phone Serial Number (beneath battery, 14 or 15 characters):

.....

Customer Service:

.....

Loss

If your phone and/or SIM card are lost or stolen, call your Service Provider immediately to prevent misuse

Accessories

Spare Battery

L 36880-N3015-A113

Identical to that supplied with your phone (NiMH 700 mAh).

Rapid Charger

L36880-N3015-A102/A103

Enables full charge in 1.5 hours.

Travel Charger

L36880-N3015-A107 ... A111

Similar to Rapid Charger but enables wordwide voltage range 90-270 V.

Desk Top Charger

L36880-N3015-A112



This forms a convenient stand, and enables easy drop in charging.
It connects to all C25 chargers.

Belt Clip

L36880-N3015-A121

This allows easy and secure attachement to a belt. The phone can rotate to a convenient angle.

Designer Cases

L36880-N3015-A122

A range of attractive protective cases are available.

Headset

L36880-N3015-A119

This offers safe high quality hands free use, whilst walking or driving.

Car Cradle
L36880-N3015-A115

Supplied with adjustable bracket this enables secure and convenient siting of your phone. Ensure vehicle operation, including Airbags, is not impeded when fixing cradles.

Antenna Cradle
L36880-N3015-A116

An external antenna avoids radiation and interference risks, and leads to increased operating range. This robust cradle provides simple automatic connection, use with other accessories, and easy handheld use.

Car Charger
L36880-N3015-A114



This fits standard cigarette lighter sockets (12-24 V). It can be used together with Passive and Antenna Cradle.

Car Kit Portable
L36880-N3015-A117



This enables safe handsfree use, as well as rapid charging, and auto answer. It simply plugs into standard cigarette lighter sockets, enabling easy movement between vehicles.
It can be used together with Car and Antenna Cradle.

Car Kit Comfort
L36880-N3015-A118



This enables natural, high speech quality and safe communication when on the move. It incorporates advanced full duplex digital technology.

Car Handset
L36880-N3015-A123

This enables optimum private use whilst connected to Car Kit Comfort.

International Code

Algeria +213	Germany +49	Malaysia +60	Spain +34
Andorra +376	Greece +30	Malta +356	Sri Lanka +94
Argentina +54	Hongkong +852	Mauritius +230	Sudan +249
Australia +61	Hungary +36	Mexico +52	Sweden +46
Austria +43	Iceland +354	Morocco +212	Switzerland +41
Bahrain +973	India +91	Myanmar +95	Syria +963
Belgium +32	Indonesia +62	Netherlands +31	Taiwan +886
Brazil +55	Iran +98	New Zealand +64	Thailand +66
Brunei +673	Iraq +964	Norway +47	Tunisia +216
Bulgaria +359	Ireland +353	Pakistan +92	Turkey +90
Canada +1	Israel +972	Poland +48	U. Arab Emirates +971
China +86	Italy +39	Portugal +351	United Kingdom +44
Croatia +385	Japan +81	Romania +40	United States +1
Czech Republic +420	Jordan +962	Russia +7	Vietnam +84
Denmark +45	Kuwait +965	Saudi Arabia +966	
Dubai +971	Lebanon +961	Singapore +65	
Egypt +20	Luxembourg +352	Slovenia +38	
Finland +358		Slow. Republic +421	
France +33		South Africa +27	

International Service Numbers

Austria	Siemens	+43 117075004	Lebanon	F.A. Kettaneh	+9611 443043
Australia	Siemens	+611800 622414	Luxembourg	Siemens	+352 438 43 399
Bangladesh	Siemens	+88017527447	Malaysia	Hello service	+6032415993
Belgium	Siemens	+3278152221	Marocco	SETEL S.A	+212235 2409
Brunei	DST	+6732 151	Mauritius	Ireland Blyth	+230211 6213
Bulgaria	Omnitel	+3592 739488	Netherlands	Siemens	+3170 333 3100
China	Siemens	+862150318149	New Zealand	Siemens	+64800800476
Croatia	Siemens	+38516105381	Norway	Siemens	+4722 633 314
Czech Republic	Siemens	+4202 24199 259	Pakistan	Siemens	+92215662200
Denmark	Siemens	+4544 77 48 66	Philippines	Siemens	+6328149888
Egypt	Siemens	+20233 13129	Poland	Siemens	+48800 220990
Finland	Siemens	+35895105 3190	Portugal	Siemens	+3511 417 8393
France	Siemens	+3301 49 22 42 84	Russia	Siemens	+7095 7371801
Germany	Siemens	+49180 5333 226	Saudi Arabia	Arabia Electric	+96626655 058
Greece	Siemens	+301 686 4389	Singapore	Siemens	+658454818
Hong Kong	Siemens	+8522870 7559	Slovenia	Siemens	+386611746333
Hungary	Siemens	+3614572444	South Africa	Siemens	+0800 11 4050
Iceland	Smith & Norland	+354511 3000	Spain	Siemens	+902 115061
India	Siemens	+911 16923988	Sweden	Siemens	+46(0) 8 7281400
"	"	+91 116925589 (ISDN)	Switzerland	Siemens	+411495 4487
Indonesia	Dian Graha Elektr.	+62214 615081	Taiwan	Siemens	+8862 2518 6504
Ireland	Siemens	+3531 6032480	Thailand	Siemens	+6626791777
Italy	Siemens	+392 4388 3091	Turkey	SIMKO	+90212 293 4160
Jordan	F.A. Kettaneh	+9626 43 98642	United Arab. Emirates	Siemens	+971271 3500
Kuwait	NGEECO	+965481 8749	United Kingdom	Siemens	+44990 334411
			Vietnam	Opticom	+8490 45 67 89

A

Alternative Line 5
Answering a Call 5
Applications 8, 22
Auto Answer 22
Auto Network 20
Auto Redialling 4

B

Babysitter 21
Battery 2, 26

C

Call Mailbox 16
Call Waiting 8, 9
Calling Back 5
Cell Broadcast 15
Change Network 20
Charge Limit 18
Charger 26
Charging Time 2

D

Deleting Messages ...12
Diacritic Marks 14
Dialling with Keypad 3
Divert 16, 19
DTMF Code 7

E

Electrostatic Charges 25
Emergency Call 3
Ending Calls 5

H

Hold Call 9

I

International Dialling 5

J

Join 9

K

Key Sound 17

L

Language 20
Last Calls 4
Licensing 25
Lock VIP Dial 21

M

Menu
  Short Cut 10
  Use 10
Message
  List 13
Minute Beep 18
Missed Calls 5
Multi Party Calls 9

N

Network
  Connection 3
  Info 20
  List 20
Network Setup 19

O

Operator List 20
Other characters 14
Own Number 7

P

PhoneBook
  Calling from 6
  Changing Entries 7
  Checking Capacity 7
PIN 3
PIN error 23
Preferred Network 20
PUK 23

R

Record Melody 17
Recording a Number ...8
Ringer
  Compose own Meldoy
  Melody 17
  Volume 17

S

Security 21
Service Tones 17
Services PhoneBook ... 7
Signal strength 3
SIM Card 2
SIM error 23
Swap 9

T

Talktime 2
Text Messages 12
  Reading 12
  Replying 14
  Sending 13
Text MessageType ... 20
Time/Charge 18
Total Calls 18
Trouble Shooting 23, 24

U

Unwanted Calls 5
Usage Time 2

V

VIP Dial 11
Voice Mail 16
  Hearing 16
  Setup 16
Volume Control 8

W

Weak signal 23
Writing Letters 14
Writing Names 6

Issued by
Information and Communication Products
Hofmannstr. 51
D-81359 München

© Siemens AG 1998
All rights reserved. Subject to availability.
Rights of modification reserved.

Siemens Aktiengesellschaft
http://www.siemens.de

Ref. No. : A31003-H3050-A1-2-7619
(20.05.1999)